

CONVERT ASI-X PACKER TO VSI-X PACKER

7" X 2-7/8"

Manual No: **DL-603-7000-503**

Revision: A

Revision Date: **05/25/2012**

Approved by :D.Hushbeck

A) DESCRIPTION

Authored by: B.Mathis

The D&L ASI-X Packer and VSI-X Packer use many of the same components. This describes how to convert an ASI-X to a VSI-X.

It is not necessary to completely disassemble the ASI-X unless the tool has been in service. If the tool has been in service, please follow D&L's recommendation for redressing.

NOTE₁: To redress tool assembly, follow disassembly instructions. It is recommended by D&L Oil Tools to replace all seals, elements, o-rings, shear screws, etc. when redressing tool.

B) CONVERSION NOTES

- B-1) Compared to ASI-X Packer:
 - VSI-X Packer does not use: Drag blocks or drag block springs
 - B-1.1) VSI-X Packer uses different P/N's for:
 - J-body
 - Rubber mandrel cap
 - Rubber retainer
 - Spring cage
 - Spring cage cap
 - Top sub
 - B-1.2) VSI-X Packer uses additional P/N's:
 - Shear screws (2375# ea)
 - Shear screws (5500# ea)

NOTE₂: 5500# shear screws are for stinger to setting equipment.

C) DISASSEMBLY

C-1) Follow disassembly instructions for 7" X 2-7/8" ASI-X Packer (tech manual *DL-603-7000-049*).

D) ASSEMBLY

D-1) Follow assembly instructions for 7"X 2-7/8" VSI-X Packer (tech manual *DL-603-7000-078*) with following notes:

NOTE₃: Do not install drag blocks or drag block springs.

NOTE₄: Replace the J-body, rubber mandrel cap, rubber retainer, spring cage, spring cage cap, and top sub with different P/N's for the VSI-X Packer.

NOTE₅: Install shear screws (2375#ea) and shear screws (5500# ea) per assembly instructions – shear screws are not used in ASI-X Packer.

D & L OIL TOOLS

P.O. BOX 52220 TULSA, OK 74152

PHONE: (800) 441-3504 www.dlmfg.com