



WIRELINER ADAPTER KIT

FOR DUAL BORE RSB PACKER

5-1/2" X 4.000" X 3.000"

Manual No:
DL-269-5500-751

Revision: **C**

Revision Date:
08/03/2023

Authored by: *J.Anderson*

Approved by: *J.McArthur*

A) DESCRIPTION

The Wireline Adapter Kit (WLAK) for Dual Bore Retrievable Seal Bore (RSB) Packer is used set the packer on electric wireline or with a compatible hydraulic setting assembly on tubing.. The WLAK is designed to be used on a Baker E-4 wireline powder charge, hydraulic setting assembly or any setting assembly with the same configuration.

The WLAK automatically disconnects from the packer during packer setting to be easily retrieved and prepared to run again.

NOTE₁: Refer to applicable RSB Packer technical manual(s) for packer specific technical information including operating procedures and packer disassembly.

B) RELATED TOOLS (sold separately)

B-1) 5-1/2" X 4.000" X 3.000" Dual Bore RSB Packer (P/N varies)—refer to applicable technical manual.

C) SPECIFICATION GUIDE

CASING SIZE (INCHES)	TOOL OD (INCHES)	PRESSURE SETTING TOOL	PART NUMBER
5-1/2	4.50	#20 BAKER E-4	26955 26955-120 ¹

¹10 ft seal bore

D) PRE-INSTALLATION INSPECTION PROCEDURES

CAUTION: D&L ships tool connections made-up **HAND TIGHT**—labeled with hand-tight tape on the tool (Fig. 1)—unless stated otherwise. Tighten/torque all connections properly before operating tool.



Fig. 1

GENERAL THREAD CONNECTION TORQUE RECOMMENDATIONS			
STUB ACME / ACME THREADS	INTERNAL TAPERED TUBING THREADS		PREMIUM THREADS
	UP TO 2-3/8"	GREATER THAN 2-3/8"	
600 – 800 FT-LBS	600 – 800 FT-LBS	800 – 1,200 FT-LBS	Consult thread manufacturer's recommendations.

GENERAL SCREW TORQUE RECOMMENDATIONS									
SCREW SIZE (INCHES)	#6	#8	#10	1/4	5/16	3/8	7/16	1/2	5/8 and larger
TORQUE RANGE (INCH-POUNDS)	5 – 8	10 – 15	18 – 25	25 – 40	50 – 80	90 – 135	160 – 210	250 – 330	450 - 650

Before first use, D&L recommends disassembly and inspection of the tool unless stated otherwise. Ensure parts have not been damaged during shipping. Replace damaged parts with D&L replacement parts. Contact D&L sales for replacement part information.

Re-assemble the tool after inspection. Install parts in the correct order and orientation. Properly tighten connections.

Before re-using the tool, D&L recommends disassembly and inspection of the tool. Clean parts and ensure parts are in good working condition. Replace worn or damaged parts with D&L replacement parts.

D & L OIL TOOLS
P.O. BOX 52220 TULSA, OK 74152
PHONE: (800) 441-3504 www.dloiltools.com



WIRELINER ADAPTER KIT

FOR DUAL BORE RSB PACKER

5-1/2" X 4.000" X 3.000"

Manual No:
DL-269-5500-751

Revision: **C**

Revision Date:
08/03/2023

Authored by: J.Anderson

Approved by: J.McArthur

D) PRE-INSTALLATION INSPECTION PROCEDURES (cont'd)

When redressing the tool, D&L recommends replacement of all shear pins, etc. Contact D&L sales for replacement part information.

E) OPERATING PROCEDURES

Assemble WLAK to packer and pressure setting assembly. Run assembly to the desired depth. Follow pressure setting assembly manufacturer's procedures for setting equipment. The WLAK disconnects from the packer as part of the setting procedure. After setting packer, retrieve setting assembly and disassemble.

F) STORAGE RECOMMENDATIONS

When preparing the tool for storage, follow the Pre-Installation Inspection Procedures. Re-assemble the tool with connections hand-tight only and in running position if applicable.

Store the tool, if possible, in an enclosed, temperature and humidity controlled environment. Avoid excessively high temperatures over long periods of time. Keep tool dry and protected from condensation. Do not store in contact with or near volatile or corrosive chemicals. Do not store near ozone generating equipment or operations such as welding.

G) RECOMMENDED HAND TOOLS

- VISE
- GLOVES
- ALLEN WRENCHES
- TAPE MEASURE
- O-RING PICK
- BAR
 - 1/2-INCH
 - 3/4-INCH
- PAINT BRUSH, 2-INCH
- PIPE WRENCH, 3-FT (2 EA)
- "CHEATER" PIPE, 4-FT LONG
- ADJUSTABLE WRENCH, 12-INCH
- CORDLESS DRILL, 18V
- SNAP RING SPREADER PLIERS
- ALIGNING PUNCH
- SCREWDRIVER SET, FLAT-TIPPED
- SOCKET SETS
 - 3/8-INCH DRIVE
 - 1/2-INCH DRIVE
- HAMMERS
 - SLEDGE
 - BALL PEEN
 - DEAD BLOW

H) ASSEMBLY ONTO PRESSURE SETTING ASSEMBLY AND PACKER

NOTE: Clean and inspect all parts. Replace all worn and damaged parts. Install parts in proper order, and orientation and tighten/torque all connections properly.

H-1) Install setting sleeve (1) onto pressure setting assembly.

H-2) Screw outer adapter (3) onto pressure setting assembly.

H-3) Screw set screws (5) into outer adapter (3).

H-4) Assemble inner adapter assembly and install into RSB packer:

H-4.1) Screw inner adapter (2) onto inner adapter extension (4).

H-4.2) Screw set screws (7) into inner adapter (2).

H-4.3) Unscrew and remove upper seal bore of RSB packer from packer.

H-4.4) Install inner adapter (2) into mandrel top of RSB packer.

H-4.5) Align holes in inner adapter (2) with holes in mandrel top (2) of packer and install driv-lok pins (8).

H-4.6) Screw upper seal bore of RSB packer back onto packer.

H-5) Screw inner adapter extension (4) onto pressure setting assembly.

H-6) Slide setting sleeve (1) down on pressure setting assembly and screw onto outer adapter (3) setting sleeve shoulders up against upper seal bore of RSB packer.

H-7) Screw set screws (6) into inner adapter extension (4). Rotate setting sleeve (1) to access threaded holes in inner adapter extension (4).

H-8) Screw set screws (6) into setting sleeve (1).



WIRELINER ADAPTER KIT

FOR DUAL BORE RSB PACKER

5-1/2" X 4.000" X 3.000"

Manual No: DL-269-5500-751
Revision: C
Revision Date: 08/03/2023

Authored by: J.Anderson

Approved by: J.McArthur

I) DISASSEMBLY FROM PRESSURE SETTING ASSEMBLY

- NOTE3:** Pressure setting assembly is not part of WLAK and is not shown.
- I-1) Unscrew and remove set screws (6) from setting sleeve (1).
 - I-2) Unscrew and remove setting sleeve (1) from pressure setting assembly.
 - I-3) Unscrew and remove set screws (7) from inner adapter (2).
 - I-4) Unscrew and remove inner adapter (2) from inner adapter extension (4).
 - I-5) Unscrew and remove set screws (6) from inner adapter extension (4).
 - I-6) Unscrew and remove inner adapter extension (4) from pressure setting assembly.
 - I-7) Unscrew and remove set screws (5) from outer adapter (3).
 - I-8) Unscrew and remove outer adapter (3) from pressure setting assembly.

J) PARTS LIST

ITEM	QTY	DESCRIPTION	MATERIAL	P/N 26955	P/N 26955-120
1	1	SETTING SLEEVE	DLMS110	26755470	
2	1	INNER ADAPTER	DLMS110	26755460	
3	1	OUTER ADAPTER	DLMS110	97120102	
4	1	INNER ADAPTER EXTENSION	DLMS110	26955466	26955466-120
5	2	SET SCREW 1/4-20 UNC X 1/4	STEEL	SSS025C025	
6	6	SET SCREW 5/16-18 UNC X 3/8	STEEL	SSS031C037	
7	2	SET SCREW 5/16-18 UNC X 7/16	STEEL	SSS031C043	
8	10	DRIV-LOK PIN (4800#) 5/16 X 1"	4140	DLP031100	

ASSEMBLED WEIGHT		88 LBS	174 LBS
------------------	--	--------	---------

NOTE4: Wireline pressure setting assembly sold separately by other manufacturer.



WIRELINER ADAPTER KIT

FOR DUAL BORE RSB PACKER

5-1/2" X 4.000" X 3.000"

Manual No:
DL-269-5500-751


Revision: **C**

Revision Date:
08/03/2023

Authored by: *J.Anderson*

Approved by: *J.McArthur*

K) TECHNICAL ILLUSTRATION



L) REVISION HISTORY

DATE	REVISION	DECIPTION OF CHANGES	REVISED BY	APPROVED BY
08/03/2023	C	Added P/N 26955-120	J.Anderson	D.McKeon
05/13/2016	B	Added General Screw Torque Recommendations, DLP031100	J.Anderson	C.Colvin
09/11/14	A	Created new manual	-	-