

7-5/8" X 3-1/2"

Manual No: DL-601-7625-649

Revision: **B**

Revision Date: 01/16/2014

Authored by: J.Anderson

Approved by: K.Plunkett

A) DESCRIPTION

The D&L VSI-X Single String Double Grip Production Packer is one of the most versatile packers on the market. The VSI-X is a modification of the ASI-X Packer with the added advantage of being able to set on electric line or hydraulically.

An On-Off Tool Stinger with Wireline Plug installed can be attached to the top of the packer. The packer can then be lubricated in the hole and set under pressure. Once the packer is set, casing pressure can be bled off, and the tubing with the On-Off Tool Overshot is run and latched onto the packer. The wireline plug can then be retrieved.

The VSI-X Packer can be easily converted to a mechanically set ASI-X Packer by removing the shear screws and installing drag blocks. The ASI-X packer is set with 1/4 right-hand rotation; and released with 1/4 right-hand rotation and can be left in tension, compression or neutral.

NOTE₁: Stinger, WLAK and pressure setting equipment sold separately.

- **NOTE₂**: This packer requires at least a 30 second burn on the wireline setting tool to ensure a proper set. A burn time less than 30 seconds may shear the setting tool off of the packer <u>before</u> fully setting the packer.
- **NOTE**₃: Uses the 7" and 7-5/8" X 3-1/2" WLAK (P/N 97174). Refer to Technical Manual *DL*-971-7000-247 for technical info.

B) SPECIFICATION GUIDE

CASING		RECOMMENDED	TOOL OD	TOOL ID	THREAD CONNECTION	PART
SIZE (INCHES)	WEIGHT (LBS/FT)	HOLE SIZE (INCHES)	(INCHES)	(INCHES)	BOX UP / PIN DOWN	NUMBER
7-5/8	24.0 - 29.7#	6.875 - 7.025	6.672	3.00	3-1/2 EUE	60178C 60178HC ¹ 60178VC ²

¹HSN Option ²Viton Option

NOTE₄: Tools listed are right-hand set / right-hand release.

DIFFERENTIAL	TENSILE LOAD
PRESSURE	THRU TOOL
(MAX)	(MAX)
7,000 PSI	105,000 LBS

D & L OIL TOOLS P.O. BOX 52220 TULSA, OK 74152 PHONE: (800) 441-3504 <u>www.dloiltools.com</u>



7-5/8" X 3-1/2"

Manual No: **DL-601-7625-649**

Revision: **B**

Revision Date:

Authored by: J.Anderson

01/16/2014

Approved by: K.Plunkett

C) RELEASING PROCEDURES

Set down weight on the packer and rotate the tubing 1/4 turn to the right at the packer and pick up while holding righthand torque. The internal by-pass will open, allowing pressure to equalize. After pressure is equalized, continue to pick up to release the upper slips, relax the elements and release the lower slips.

In the event, the packer will not release in the normal manner, hard right-hand torque can be applied (800-1000 Ft-lbs) which will break the tack weld on the J-pin ring. Continued rotation of approximately 15 turns will release the J-pin ring and allow the packer to be pulled. When released in this manner, the packer will reset when moved down the hole.

CAUTION₁: High differential pressure below the VSI-X may cause the upper slips to wedge in tighter, requiring an extra amount of tension to release the upper slips.

PACKER SIZE	TUBING SIZE		ESSURE INCHES)
(INCHES)	(INCHES)	ABOVE	BELOW
	2.375	6.43 DOWN	7.59 UP
7-5/8" X 3-1/2"	2.875	4.37 DOWN 6.19 UI	6.19 UP
	3.500	1.24 DOWN	3.47 UP

D) PRESSURE AFFECTED AREA GUIDE

Example: Consider a 7-5/8" X 3-1/2" VSI-X Packer set on 2.875" tubing with a differential pressure of 3,000 PSI in the annulus around the tubing above the packer. How much force is acting on the seal area of the mandrel?

To calculate the force (lbs) acting on the seal area of the mandrel, refer to the pressure affected area guide for a 7-5/8" X 3-1/2" VSI-X Packer run on 2.875" tubing. In this example, the differential pressure from above the packer acts down on the seal area of the mandrel area across a pressure affected area of 4.37 in². Multiplying the differential pressure (3,000 PSI) by the pressure affected area (4.37 in²) results in a downward force of 13,110 lbs. 13,110 lbs is the force which needs to be neutralized when releasing the packer.

E) ELEMENT SELECTION GUIDE

NITRILE (STD)				
TEMPERATURE	DUROMETER			
RANGE (F°)	END	MIDDLE	END	
70° - 125°	80	70	80	
125° - 250°	90	70	90	
250° - 300°	90	80	90	
300° +	Contact D&L Sales			

RUBBER TYPE	TEMPERATURE RANGE
NITRILE	70° - 300°F
HSN (HNBR)	70° - 325°F
VITON	100° - 350°F



7-5/8" X 3-1/2"

Manual No: DL-601-7625-649

Revision: **B**

Revision Date: 01/16/2014

Approved by: K.Plunkett

Authored by: J.Anderson

F) RECOMMENDED TOOLS

F-1) HAND TOOLS

- VISE
- GLOVES
- ALLEN WRENCHES
- TAPE MEASURE
- O-RING PICK
- BAR
- 1/2-INCH
- 3/4-INCH

F-2) SPECIAL TOOLS

- PAINT BRUSH, 2-INCH
- PIPE WRENCH, 3-FT (2 EA)
- "CHEATER" PIPE, 4-FT LONG
- ADJUSTABLE WRENCH, 12-INCH
- CORDLESS DRILL, 18V
- SNAP RING SPREADER PLIERS
- ALIGNING PUNCH

- SCREWDRIVER SET, FLAT-TIPPED
- SOCKET SETS
- 3/8-INCH DRIVE
- 1/2-INCH DRIVE
- HAMMERS
- SLEDGE
- BALL PEEN
- DEAD BLOW

ITEM	QTY	DESCRIPTION	PART NUMBER
T1	1	ASSEMBLY TOOL 4-1/2" - 7-5/8" VSI-XW	AT100

G)DISASSEMBLY

- G-1) Clamp spring cage (5) in vise.
 - G-1.1) Unscrew and remove set screws (30) from drag block body (18). Rotate drag block retainer (21) as needed to access screws.
 - G-1.2) Unscrew and separate drag block body (18) from J-body (20) (NOTE₅: Left-hand threads). **NOTE**₆: Drag block body assembly must be free to rotate.
 - G-1.3) Unscrew and remove shear screws (3) from J-body (20).
 - G-1.4) Unscrew and remove set screws (28) from J-pin bottom sub (23). Move J-body (20) as needed to access screws.
 - G-1.5) Unscrew and remove J-pin bottom sub (23) from inner mandrel (2).

G-1.5.1) Remove o-ring (35) from J-pin bottom sub (23).

- G-1.6) Remove J-body (20) from inner mandrel (2).
- G-1.7) Unscrew and remove rubber mandrel cap (19) from rubber mandrel (11).

NOTE₇: For added leverage, insert a rod through rubber retainer (15) and rubber mandrel (11) as needed.

- G-1.8) Remove drag block retainer (21) from drag block body (18).
- G-1.9) Remove drag block body assembly and disassemble:
 - G-1.9.1) Wedge lower slips (17) outwards (if needed). Unscrew and remove cap screws (33) from drag block body (18).
 - G-1.9.2) Remove lower slip support (31) from drag block body (18).
 - G-1.9.3) Remove wedges (if needed). Remove lower slips (17) and lower slip springs (25) from drag block body (18).
- G-1.10) Unscrew and remove lower cone (16) from rubber retainer (15).
- G-1.11) Unscrew rubber mandrel (11) from center coupling (10).

NOTE₈: For added leverage, insert a rod through upper cone (9) as needed.

- G-1.12) Remove rubber mandrel assembly and disassemble:
 - G-1.12.1) Remove elements (13, 14), rubber spacers (12), and rubber retainer (15) from rubber mandrel (11). G-1.12.1.1) Unscrew and remove gage ring (29) from rubber retainer (15).



7-5/8" X 3-1/2"

Manual No: **DL-601-7625-649**

Revision: B


Revision Date:

Authored by: J.Anderson

01/16/2014 Approved by: K.Plunkett

G) DISASSEMBLY (cont'd)

- G-1.13) Unscrew and remove center coupling (10) from upper cone (9).
 - G-1.13.1) Remove bonded seal (24) and o-ring (36) from center coupling (10).
 - G-1.13.1.1) Remove o-ring (34) from bonded seal (24).
- G-1.14) Remove upper cone (9) from inner mandrel (2).
- G-1.15) Wedge slips (7, 8) outwards (if needed). Unscrew and remove inner mandrel (2) from top sub (1).
- G-1.16) Remove wedges (if needed). Remove releasing slip (7), upper slips (8) and upper slip springs (26) from spring cage (5).



- G-1.17) Disassemble spring cage assembly:
 - G-1.17.1) Unscrew spring cage cap (27) from spring cage (5).
 - G-1.17.2) Position assembly tool (T1) hand-tight against top sub (1) and upper slip support (32) of spring cage assembly (Fig. 1).
 - **CAUTION**₂: Compression spring (4) is compressed with tension against spring cage assembly.
 - G-1.17.3) Unscrew and remove shear screws (3) from spring cage (5).
 - G-1.17.4) Release compression spring (4) tension by loosening assembly tool (T1). Remove tool from assembly.
 - G-1.17.5) Remove spring cage cap (27), top sub (1), and compression spring (4) from spring cage (5).
 - G-1.17.6) Unscrew and remove upper slip body (6) from upper slip support (32).
 - G-1.17.7) Unscrew and remove upper slip support (32) from spring cage (5).
 - G-1.17.8) Remove spring retainer ring (22) from upper slip body (6).
- G-2) Remove spring cage (5) from vise.

H)ASSEMBLY

NOTE₉: Clean and inspect all parts. Replace all worn and damaged parts. Install parts in proper order and orientation.

- H-1) Clamp spring cage (5) in vise.
 - H-1.1) Assemble spring cage assembly:
 - H-1.1.1) Install spring retainer ring (22) into upper slip support (32).
 - H-1.1.2) Screw upper slip support (32) onto spring cage (5).
 - H-1.1.3) Install upper slip springs (26), upper slips (8), and releasing slip (7) into upper slip body (6). Wedge releasing slip (7) and upper slips (8) outwards.

NOTE₁₃: Install two (2ea) springs per slip (Fig. 2).

H-1.1.4) Screw upper slip body (6) onto upper slip support (32). Remove wedges.



Fig. 2



7-5/8" X 3-1/2"

Manual No: **DL-601-7625-649**

Revision: **B**

Revision Date:


Authored by: J.Anderson

01/16/2014 Approved by: K.Plunkett

H) ASSEMBLY (cont'd)

H-1.1.5) Install compression spring (4) and top sub (1) into spring cage (5).

NOTE₁₀: Press down top sub (1) to compress compression spring (4) as needed.



- H-1.1.6) Compress compression spring (4) with assembly tool (T1) (Fig. 3).
- H-1.1.7) Align threaded holes in spring cage (5) with recessed holes in top sub (1). Screw shear screws (3) into spring cage (5). Tighten until shear screws (3) make contact with top sub (1). Back shear screws (3) out 1/4 turn.
- H-1.1.8) Remove assembly tool (T1) from spring cage assembly.

CAUTION₂: Compression spring (4) is compressed with tension against spring cage assembly.

- H-1.1.9) Screw spring cage cap (27) onto spring cage (5).
- H-1.2) Screw inner mandrel (2) into top sub (1).
- H-1.3) Insert upper cone (9) onto inner mandrel (2).
- H-1.4) Install o-ring (34) in groove in bonded seal (24).
- H-1.5) Install bonded seal (24) into center coupling (10).

CAUTION₃: Do not rip or tear o-ring during installation.

- H-1.6) Install o-ring (36) in groove in center coupling (10).
- H-1.7) Screw center coupling (10) into upper cone (9).

NOTE₈: For added leverage, insert a rod through upper cone (9) as needed.

- H-1.8) Screw gage ring (29) onto center coupling (10).
- H-1.9) Assemble rubber mandrel assembly and install:
 - H-1.9.1) Screw gage ring (29) onto rubber retainer (15).
 - H-1.9.2) Install rubber retainer (15), elements (13, 14), and rubber spacers (12) onto rubber mandrel (11).
 - H-1.9.3) Install rubber mandrel assembly onto inner mandrel (2).
 - H-1.9.4) Screw rubber mandrel (11) into center coupling (10).

CAUTION₃: Do not rip or tear o-ring during installation.

- H-1.10) Screw lower cone (16) into rubber retainer (15).
- H-1.11) Assemble drag block body assembly and install:
 - H-1.11.1) Install lower slips (17) and lower slip springs (25) into drag block body (18).

NOTE₁₃: Install two (2ea) springs per slip (Fig. 4).

- H-1.11.2) Wedge lower slips (17) outwards. Install lower slip support (31) into drag block body (18).
- H-1.11.3) Align pocket holes in lower slip support (31) with threaded holes in drag block body (18). Screw cap screws (33) into drag block body (18). Remove wedges.
- H-1.11.4) Install drag block body assembly onto rubber mandrel (11).



Fig. 4



7-5/8" X 3-1/2"

Manual No: **DL-601-7625-649**

Revision: **B**

Revision Date:

Authored by: J.Anderson

01/16/2014 Approved by: K.Plunkett

H) ASSEMBLY (cont'd)

H-1.12) Screw rubber mandrel cap (19) onto rubber mandrel (11).

NOTE₇: For added leverage, insert a rod through rubber retainer (15) and rubber mandrel (11) as needed.

- H-1.13) Install drag block retainer (21) onto J-body (20).
- H-1.14) Install J-body (20) onto inner mandrel (2) and over rubber mandrel cap (19). Do not screw J-body (20) at this time.
- H-1.15) Install o-ring (35) in groove in J-pin bottom sub (23).
- H-1.16) Install J-pin bottom sub (23) in J-slots in J-body (20). Screw J-pin bottom sub (23) onto inner mandrel (2). **CAUTION**₃: Do not rip or tear o-ring during installation.
- H-1.17) Screw set screws (28) into J-pin bottom sub (23). Move J-body (20) as needed to access threaded holes in J-pin bottom sub (23).



- H-1.18) Position J-pin of J-pin bottom sub (23) on tension shoulder in J-slot of J-body (20). Rotate J-body (20) as necessary (Fig. 5).
- H-1.19) Align threaded holes in J-body (20) with recessed holes in rubber mandrel cap (19). Screw shear screws (3) in J-body (20). Tighten until shear screws (3) make contact with rubber mandrel cap (19). Back shear screws (3) out 1/4 turn.

NOTE₁₁: If needed, back off J-pin bottom sub (23). No more than 1/8 turn (45°) should be needed.

H-1.20) Screw drag block body (18) into J-body (20). (NOTE₅: Left-hand threads).

NOTE₆: Drag block body assembly must be free to rotate.

- H-1.21) Screw set screws (30) into drag block body (18).
- H-2) Unclamp spring cage (5) from vise and remove assembled tool.

I) PARTS LIST

ITEM	QTY	DESCRIPTION	MATERIAL	P/N 60178C (24.0 – 29.7#)
1	1	TOP SUB	1026	60173610
2	1	INNER MANDREL	1026	60373210
3	16	SHEAR SCREW (2375#)	BRASS	60100990
4	1	COMPRESSION SPRING	CHROME VANADIUM	60373920
5	1	SPRING CAGE	1026	60174310
6	1	UPPER SLIP BODY	1026	60377320
7	1	RELEASING SLIP	P-110	60075125
8	2	UPPER SLIP - CARBIDE	P-110	60075115C
9	1	UPPER CONE	1026	60377410



7-5/8" X 3-1/2"

Manual No:

DL-601-7625-649

Revision: **B**

Revision Date:

Authored by: J.Anderson

01/16/2014 Approved by: K.Plunkett

I) PARTS LIST (cont'd)

ITEM	QTY	DESCRIPTION	MATERIAL	P/N 60178C (24.0 – 29.7#)
10	1	CENTER COUPLING	1026	60273620
11	1	RUBBER MANDREL	1026	60073220
12	2	RUBBER SPACER	1026	60378840
13	1	ELEMENT	70 DURO NITRILE	60278511
14	2	ELEMENT	90 DURO NITRILE	60278513
15	1	RUBBER RETAINER	1026	60377850
16	1	LOWER CONE	1026	60377421
17	4	LOWER SLIP - CARBIDE	P-110	60075135C
18	1	DRAG BLOCK BODY	1026	60377335
19	1	RUBBER MANDREL CAP	1026	60173230
20	1	J-BODY ASSY	1026	60173340
21	1	DRAG BLOCK RETAINER	1026	60377910
22	1	SPRING RETAINER RING	1026	60073820
23	1	J-PIN BOTTOM SUB	P-110/1026	60373650
24	1	BONDED SEAL	90 DURO NITRILE	60073520
25	8	LOWER SLIP SPRING	ELGILOY	7170901
26	6	UPPER SLIP SPRING	ELGILOY	7170902
27	1	SPRING CAGE CAP	1026	60174810
28	2	SET SCREW 1/4-20 UNC X 3/8	STEEL	SSS025C037
29	2	GAGE RING	1026	60378830
30	3	SET SCREW 3/8-16 UNC X 1/2	STEEL	SSS037C050
31	1	LOWER SLIP SUPPORT	1026	60377912
32	1	UPPER SLIP SUPPORT	1026	60377880
33	2	CAP SCREW 3/8-16 UNC X 3/4	STEEL	SCS037C075
34	1	155 O-RING	90 DURO NITRILE	90155
35	1	237 O-RING	90 DURO NITRILE	90237
36	1	243 O-RING	90 DURO NITRILE	90243
37	8	SHEAR SCREW (5500#) 1/2-13 UNC X 7/16	BRASS	BSSSLT050C043*

REDRESS KIT (RDK)	60178050
ASSEMBLED WEIGHT	360 LBS



7-5/8" X 3-1/2"

Manual No: **DL-601-7625-649**

Revision: **B**

Revision Date: 01/16/2014

Authored by: J.Anderson

Approved by: K.Plunkett

J) OPTIONS PARTS LIST

J-1) HSN

NOTE₁₂: For temperature range, refer to element selection guide.

ITEM	QTY	DESCRIPTION	MATERIAL	P/N 60178HC (24.0 - 29.7#)
13	1	ELEMENT	70 DURO HSN	60278511H
14	2	ELEMENT	90 DURO HSN	60278513H
34	1	155 O-RING	90 DURO HSN	90155H
35	1	237 O-RING	90 DURO HSN	90237H
36	1	243 O-RING	90 DURO HSN	90243H

REDRESS KIT (RDK)	60178050H
-------------------	-----------

J-2) VITON

NOTE₁₂: For temperature range, refer to element selection guide.


ITEM	QTY	DESCRIPTION	MATERIAL	P/N 60178VC (24.0 – 29.7#)
13	1	ELEMENT	70 DURO VITON	60278511V
14	2	ELEMENT	90 DURO VITON	60278513V
34	1	155 O-RING	90 DURO VITON	90155V
35	1	237 O-RING	90 DURO VITON	90237V
36	1	243 O-RING	90 DURO VITON	90243V

REDRESS KIT (RDK)		60178050V
-------------------	--	-----------

VSI-X PACKER W/ CARBI 7-5/8" X 3-1/2"		Manual No: DL-601-7625-649
		Revision: B
		Revision Date: 01/16/2014
Authored by: J.Anderson		Approved by: K.Plunkett

K) TECHNICAL ILLUSTRATION





	VSI-X PACKER W/ CARBIDE 7-5/8" X 3-1/2"	Manual No: DL-601-7625-649	
		Revision: B	
OIL TOOLS		Revision Date: 01/16/2014	
Authored by: J.Anderson		Approved by: K.Plunkett	

L) REVISION HISTORY

DATE	REVISION	DESCRIPTION OF CHANGES	REVISED BY	APPROVED BY
01/16/14	В	Revised P/N 60174310 was 60173310; Added H-1.18 to assembly and Fig. 5	J.Anderson	B.Oligschlaeger
01/10/14	А	Created new manual	-	-