

Manual No: **DL-409-3500-1407** 

Revision: **B** 

Revision Date:

09/23/2022

Authored by: J.Anderson

Approved by: K.Plunkett

## A) DESCRIPTION

The YYT Packer is an economical, compact tools for injection, pumping, medium range treating and production applications. The yo-yo design allows the packer to be set and unset without rotation of the tubing.

The packer features an adjustable straight pull safety shear release. This packer is not designed to be run in compression.

### **B) SPECIFICATION GUIDE**

CASING			NG	Т	OOL		DADT	
	SIZE (INCHES)	WEIGHT (LBS/FT)	RECOMMENDED HOLE SIZE (INCHES)	GAGE OD (INCHES)	NOMINAL ID (INCHES)	THREAD CONNECTION BOX UP / PIN DOWN	PART NUMBER	
	3-1/2	7.7 – 10.2	2.922 - 3.068	2.781	1.25	1.900 EUE	40935C-3 40935HC-3 <sup>1</sup> 40935VC-3 <sup>2</sup>	

Elastomer Trim Options: <sup>1</sup>HSN, <sup>2</sup>Viton

DIFFERENTIAL	TENSILE LOAD
PRESSURE	THRU TOOL
(MAX)	(MAX)
7,000 PSI	50,000 LBS

#### C) PRE-INSTALLATION INSPECTION PROCEDURES

CAUTION<sub>1</sub>: D&L ships tool connections made-up HAND TIGHT—labeled with hand-tight tape on the tool (Fig. 1) — unless stated otherwise. Tighten/torque all connections properly before operating tool.

Fig. 1

HAND

FIGHT	GENERAL THREAD CONNECTION TORQUE RECOMMENDATIONS								
	STUB ACME /	INTERNAL TAPI	ERED TUBING THREADS	PREMIUM THREADS					
	ACME THREADS	UP TO 2-3/8"	GREATER THAN 2-3/8"						
V	600 – 800 FT-LBS	600 – 800 FT-LBS	800 – 1,200 FT-LBS	Consult thread manufacturer's recommendations.					

	GENERAL SCREW TORQUE RECOMMENDATIONS								
SCREW SIZE (INCHES)	#6	#8	#10	1/4	5/16	3/8	7/16	1/2	5/8 and larger
<b>TORQUE RANGE</b> (INCH-POUNDS)	5-8	10 - 15	18 – 25	25 - 40	50 - 80	90 - 135	160 - 210	250 - 330	450 - 650

Before first use, D&L recommends disassembly and inspection of the tool unless stated otherwise. Ensure parts have not been damaged during shipping. Replace damaged parts with D&L replacement parts. Contact D&L sales for replacement part information.

Re-assemble the tool after inspection. Install parts in the correct order and orientation. Properly tighten connections.

Before re-using the tool, D&L recommends disassembly and inspection of the tool. Clean parts and ensure parts are in good working condition. Replace worn or damaged parts with D&L replacement parts.

D & L OIL TOOLS P.O. BOX 52220 TULSA, OK 74152 PHONE: (800) 441-3504 <u>www.dloiltools.com</u>



Manual No: **DL-409-3500-1407** 

Revision: **B** 

Revision Date:

09/23/2022

Authored by: J.Anderson

Approved by: K.Plunkett

## C) PRE-INSTALLATION INSPECTION PROCEDURES (cont'd)

When redressing the tool, D&L recommends replacement of all seals, elements, o-rings, shear screws, etc. Contact D&L sales for redress kit and/or other part information.

## **D) SETTING PROCEDURES**

CAUTION<sub>2</sub>: Do not run the tool without properly tightening connections. Running the tool with loose connections may damage the tool and cause malfunction.

Run to setting depth. Pick up on the tubing then slack off on the tubing to allow for setting stroke (5 - 6 inches) plus desired tubing load. Pull tension to set the slips and pack off the elements (min. 7,000 lbs). After setting the packer, the tubing string must be keep neutral or in tension.

## **E) RELEASING PROCEDURES**

Set down on the tubing to unset the slips, relax the packing elements and re-jay the packer. The tool may now be moved and reset or pulled from the well.

## E-1) EMERGENCY RELEASE

If the packer will not release conventionally, pick up with enough force to shear the safety shear release (adjustable up to 27,000 lbs). Once it shears, the tool must be tripped out. If the safety shear release will not shear, torque the tubing to the right until the secondary release threads break loose. Rotate 12 - 15 additional turns to the right at the tool and trip out.

## F) STORAGE RECOMMENDATIONS

When preparing the tool for storage, follow the Pre-Installation Inspection Procedures. Re-assemble the tool with connections hand-tight only and in running position if applicable. Elements should be in a relaxed state—free from tension, compression, and other stresses that could cause deformation.

Store the tool, if possible, in an enclosed, temperature and humidity controlled environment. Avoid excessively high temperatures over long periods of time. Shield elastomeric parts from ultraviolet light sources. Keep tool dry and protected from condensation. Do not store in contact with or near volatile or corrosive chemicals. Do not store near ozone generating equipment or operations such as welding.

## G) ELASTOMER TRIM TEMPERATURE GUIDE

NITRILE (STD)						
TEMPERATURE	DUROMETER					
RANGE (F°)	END	MIDDLE	END			
40° - 125°	80	70	80			
125° - 250°	90	70	90			
150° - 250°	90	80	90			
250° +	Contact D&L Sales					

RUBBER TYPE	TEMPERATURE RANGE
NITRILE	40° - 250°F
HSN (HNBR)	70° - 300°F
VITON	100° - 350°F



Manual No: **DL-409-3500-1407** 

Revision: **B** 

Revision Date: 09/23/2022

Approved by: K.Plunkett

Authored by: J.Anderson

### H) RECOMMENDED TOOLS

#### H-1) HAND TOOLS

- VISE
- GLOVES
- ALLEN WRENCHES
- TAPE MEASURE
- O-RING PICK
  - BAR
  - 1/2-INCH
  - 3/4-INCH

H-2) SPECIAL TOOLS

- PIPE WRENCH, 3-FT (2 EA)
- "CHEATER" PIPE, 4-FT LONG
- ADJUSTABLE WRENCH, 12-INCH
- CORDLESS DRILL, 18V
- SNAP RING SPREADER PLIERS
- ALIGNING PUNCH

- SCREWDRIVER SET, FLAT-TIPPED
- SOCKET SETS
- 3/8-INCH DRIVE
- 1/2-INCH DRIVE
- HAMMERS
- SLEDGE
- BALL PEENDEAD BLOW

ITEM	TEM QTY DESCRIPTION		PART NUMBER
T1	1	DRAG BLOCK ASSEMBLY TOOL	AT045110

#### I) DISASSEMBLY

- I-1) Clamp coupling (1) in vise.
  - I-1.1) Unscrew and remove shear screws (19) from shear sleeve (3).
  - I-1.2) Unscrew and remove bottom sub (4) from inner mandrel (2).
    - I-1.2.1) Remove o-ring (18) from bottom sub (4).
  - I-1.3) Remove shear sleeve (3), elements (13, 14), rubber spacers (12) and lower cone (16) from inner mandrel (2).
- I-2) Unclamp and remove coupling (1) from vise. Clamp lower end of inner mandrel (2) in vise.
  - I-2.1) Moving to upper end of tool, unscrew and remove coupling (1) from inner mandrel (2) (NOTE<sub>1</sub>: Left-hand threads).
  - I-2.2) Unscrew and remove set screws (9) from J-pin retainer (6).
  - I-2.3) Compress drag blocks (7) with drag block body assembly tool (T1).
  - I-2.4) Unscrew J-pin retainer (6) from drag block body (5) (NOTE<sub>1</sub>: Left-hand threads) and remove from inner mandrel (2).
  - I-2.5) Remove J-pin (17) from J-pin swivel (15).
  - I-2.6) Remove J-pin swivel (15) from inner mandrel (2).
  - I-2.7) Release and remove drag blocks (7) and drag block springs (10) from drag block body (5).
  - I-2.8) Wedge lower slips (8) outwards (if needed). Remove drag block body assembly and disassemble:
    - I-2.8.1) Remove wedges (if needed). Remove lower slips (8) and slip springs (11) from drag block body (5).
- I-3) Unclamp and remove inner mandrel (2) from vise.



Manual No: **DL-409-3500-1407** 

Revision: **B** 

Revision Date:

09/23/2022 Approved by: K.Plunkett

O-RING GROOVE

THREAD RELIEF

Authored by: J.Anderson

#### J) ASSEMBLY

- **NOTE<sub>2</sub>:** Clean and inspect all parts. Replace all worn and damaged parts. Install parts in proper order, and orientation and tighten/torque all connections properly.
- **CAUTION**<sub>4</sub>: To ensure tool operates properly, install o-rings in o-ring grooves <u>NOT</u> thread relief (Fig. 2).
- J-1) Clamp lower end of inner mandrel (2) in vise.
  - J-1.1) Assemble drag block body assembly and install:
    - J-1.1.1) Install lower slips (8) and slip springs (11) into drag block body (5). Wedge lower slips (8) outwards.

NOTE3: Install one (1ea) spring per slip (Fig. 3).

- J-1.1.2) Install drag block body assembly onto inner mandrel (2). Position drag block body (5) below run-in position of J-slot on mandrel (2). Remove wedges.
- J-1.2) Install drag blocks (7) and drag block springs (10) into drag block body (5). **NOTE4:** Install two (2 ea) springs per drag block (Fig. 4).
- J-1.3) Compress drag blocks (7) with drag block assembly tool (T1).





Fig. 2



- J-1.4) Install J-pin swivel (15) onto inner mandrel (2). Position swivel with J-pin hole aligned with run-in position in J-slot (Technical Illustration, Fig. 5).
- J-1.5) Install J-pin (17) into J-pin swivel (15).
- J-1.6) Install J-pin retainer (6) onto inner mandrel (2) and screw onto drag block body (5) to retain J-pin (17) and capture ends of drag blocks (7) (**NOTE**<sub>1</sub>: Left-hand threads).
- J-1.7) Screw set screws (9) into J-pin retainer (6). Release drag blocks (7).
- J-1.8) Screw coupling (1) onto inner mandrel (2) (NOTE1: Left-hand threads).
- J-1.9) Unclamp and remove inner mandrel (2) from vise. Clamp coupling (1) in vise.
- J-1.10) From lower end of tool, install lower cone (16), elements (13, 14), rubber spacers (12) and shear sleeve (3) onto inner mandrel (2).
- J-1.11) Install o-ring (18) in groove in bottom sub (4).
- J-1.12) Screw bottom sub (4) onto inner mandrel (2).

CAUTION<sub>5</sub>: Do not rip or tear o-ring during installation.

- J-1.13) Align threaded holes in shear sleeve (3) with shear screw groove in bottom sub (4). Screw desired quantity of shear screws (19) into shear sleeve (3). Tighten until shear screws (19) contact bottom sub (4). Back off 1/4 turn.
- J-2) Unclamp coupling (1) from vise and remove assembled tool.



Fig. 4



Manual No: **DL-409-3500-1407** 

Revision: B

Revision Date:

09/23/2022

Authored by: J.Anderson

Approved by: K.Plunkett

### K) PARTS LIST

ITEM	QTY	DESCRIPTION	MATERIAL	P/N 40935C-3
1	1	COUPLING	DLMS80	CP-BAA-BBA-B-1L
2	1	INNER MANDREL	DLMS110	40935213
3	1	SHEAR SLEEVE	DLMS60	40935853
4	1	BOTTOM SUB	DLMS80	40935630
5	1	DRAG BLOCK BODY	DLMS60	60330335
6	1	J-PIN RETAINER	DLMS35	40935371
7	4	CARBIDE DRAG BLOCK	DLMSDB4	9028900C
8	4	LOWER SLIP	DLMS110	40935115C
9	4	SOCKET SET SCREW 1/4-20 UNC X 3/16	STEEL	SSS025C018
10	8	DRAG BLOCK SPRING	-	9102900
11	4	SLIP SPRING	-	7125900
12	2	RUBBER SPACER	1026	72535840
13	1	ELEMENT	70 DURO NITRILE	72035511
14	2	ELEMENT	90 DURO NITRILE	72035513
15	1	J-PIN SWIVEL	DLMS35	40935801
16	1	LOWER CONE	DLMS110	72535420
17	1	J-PIN	DLMS110	40945635Y
18	1	223 O-RING	90 DURO NITRILE	90223
19	6	SLOTTED SHEAR SCREW (4500#) 7/16-14 UNC X 5/16	DLM360BRS	BSSSLT043C031

REDRESS KIT (RDK)	40935050-3
ASSEMBLED WEIGHT	28 LBS



Manual No: DL-409-3500-1407

Revision: **B** 

**Revision Date:** 

09/23/2022

Authored by: J.Anderson

Approved by: K.Plunkett

### K) PARTS LIST (cont'd)

#### **K-1) ELASTOMER TRIM OPTIONS**

NOTE5: For temperature range, refer to Elastomer Trim Temperature Guide.

K-1.1) HSN

ITEM	QTY	DESCRIPTION	MATERIAL	P/N 40935HC-3
13	1	ELEMENT	70 DURO HSN	72035511H
14	2	ELEMENT	90 DURO HSN	72035513H
18	1	223 O-RING	90 DURO HSN	90223H

REDRESS KIT (RDK)		40935050H-3
-------------------	--	-------------

K-1.2) VITON

ITEM	QTY	DESCRIPTION	MATERIAL	P/N 40935VC-3	
13	1	ELEMENT	70 DURO VITON	72035511V	
14	2	ELEMENT	90 DURO VITON	72035513V	
18	1	223 O-RING	90 DURO VITON	90223V	

|--|

	YYT PACKER, CARBIDE,	Manual No: DL-409-3500-1407	
&	<b>3 ELEMENT</b>	Revision: <b>B</b>	
OIL TOOLS	3-1/2" X 1.900"	Revision Date: 09/23/2022	
Authored by: J.Anderson		Approved by: K.Plunkett	

### L) TECHNICAL ILLUSTRATION



	YYT PACKER, CARBIDE,	Manual No: <b>DL-409-3500-1407</b>	
8	<b>3 ELEMENT</b> 3-1/2" X 1.900"	Revision: <b>B</b>	
OIL TOOLS		Revision Date: 09/23/2022	
Authored by: J.Anderson		Approved by: K.Plunkett	

### M) REVISION HISTORY

DATE	REVISION	DESCRIPTION OF CHANGES	REVISED BY	APPROVED BY
09/23/2022	В	Revised 40935115C WAS 60030135C	J.Anderson	E.Visaez
10/12/2020	А	Created new manual	-	-